


新幹線騒音の経年変化グラフ



新幹線鉄道振動の経年変化

(単位：デシベル)

測定地区	指針値	距離 [m]											
			H15	H16	H17	H18	H19	H20	H21	H22	H23	H24	H25
① 富野	70	12.5	47	46	45	45	44	46	51	45	45	43	49
		25	45	44	44	43	43	41	41	41	40	41	47
		50											
② 日明	70	12.5	52	52	51	53	52	49	48	50	49	52	52
		25	47	46	47	47	45	46	48	51	49	51	52
		50											
③ 小嶺	70	12.5	61	57	58	57	56	57	58	59	59	60	55
		25	53	50	52	50	49	49	49	51	53	51	49
		50											
④ 茶屋の原	70	12.5	56	57	55	57	56	59	57	58	56	56	56
		25	55	55	54	56	53	57	53	56	54	53	54
		50											
⑤ 楠橋	70	12.5	54	54	55	57	57	60	59	58	59	59	55
		25	52	51	53	54	55	57	60	59	57	58	57
		50											

新幹線振動の経年変化グラフ

